



## INSTRUCTION FOR APPLICATION

### TEST KIT INSTRUCTIONS FOR PRAWNFRESH AND PRAWNFRESH PLUS

IMPORTANT NOTE: Must be used in correct order – Reagent 1 then Reagent 2

- 1) The PrawnFresh solution should be made up as per the instructions and a 25 ml sample taken in the small bottle enclosed.
  
- 2) 25ml should be taken from Xyrex PrawnFresh Reagent 1 and added to the small sample jar along with the Prawn-Fresh solution.
  
- 3) 25ml should be taken from Xyrex PrawnFresh Reagent 2 and added to the small sample jar along with the Prawn-Fresh solution and Reagent 1.
  
- 4) The sample jar should then be sealed and shaken well to ensure the Solutions are well mixed.
  
- 5) The colour of the full strength solution should now resemble a clear chestnut brown similar to strong tea. Repeating the exercise with salt water only will show the colour of a solution with no additive.
  
- 6) Xyrex would recommend that the dipping solution be checked twice daily.